


- **WiPG-2000 Bottom Side**



- **WiPG-1000 / 1500 Bottom Side**



Description

Reset Button

Press reset button and power on the device to execute Hardware Reset.
